

TARGET SIGHT

Sight bracket

Screws to attach
bracket to bow

Screws to attach
bracket to sight bar

Sight bar with yardage tape

Adjust windage by loosening screw (B)
and rotating the aperture bolt to desired
setting. Lock down with screw (B)

Slide Aperture
assembly onto
the sight bar and
tighten with
adjustment screw (A)

(B)

(A)

Aperture
assembly

