



## Compatible Devices

## Incompatible Devices

<b>Acer</b>	ICONIA A1-810, ICONIA Tab A700, ICONIA W3-810	Tablet Iconia B1-A71
<b>Alcatel</b>	Alcatel is incompatible	One Touch Pop Mega, 564C, 846L
<b>Archos</b>	96 Xenon Tablet	
<b>Asus</b>	MeMO Pad 10 ME102, MeMO Pad ME172V, MeMO Pad ME301T, MeMO Pad ME302, Transformer Pad TF-100	
<b>Blu Studio</b>	Not compatible	Blu Studio Energy
<b>Blackberry Z30</b>	Z30	All other BlackBerry's
<b>Casio</b>	Casio is incompatible	Not: Gz'one or Commando
<b>Fujitsu</b>	LTE F-01D	
<b>Huawei</b>	MediaPad S7-301u(P), MediaPad 7 Lite, P6-00	Huawei H892L
<b>HTC</b>	One M8 & M9, One Max, DNA, Desire 600 One, HTC X, HTC One mini, DESIRE, Desire EYE, Desire VC T328d, HTC J	Not: HTC J, Butterfly, HTC One X
<b>InFocus</b>	M320	
<b>(Kindle devices not supported)</b>		
<b>Lenovo</b>	A3000	
<b>LG</b>	G2, G3, G4, G Vista, G Pro, G Pro 2, G Pad 7.0/8.3/10.1, Optimus-G, Optimus L90	Not: LG Optimus F7 & F3Q, LG Lancet, LG Lucid-3(VS876), LG Ultimate 2 (L41C), LG Leon LGMS345, LG L31L/L41L-Ultimate I/II, LG Access, LG F60, LG Optimus Dynamic I/II. LG Transpyre VS810PP
<b>MOBIA</b>	X8	
<b>Motorola</b> *May require Nexus Photo Viewer app	Droid Razr HD (XT926), Moto G, Moto X, Droid Mini, <b>Droid Turbo/Turbo2</b> , Droid Ultra	Razr (XT916)
<b>Nexus</b> *May require Nexus Photo Viewer app	5, 6, 7G1, 7G2, 9, 10	Not: Nexus 4
<b>Nokia</b>	Nokia N8, C6-01, C7, Oro, E6, E7, X7, 603, 701 and 808 Pureview	
<b>Prestigio</b>	Multipad Thunder 8.0I 3g	
<b>Samsung</b>	Galaxy S2, S2 Plus, S3, S4, S4-Zoom, S4/S5 Active, S5, S6, S6 EDGE Galaxy Avant, Galaxy R, Galaxy J, Galaxy Mega 6.3, Galaxy A7, Galaxy J, WIN Galaxy Note, Note 2, 3, 4, 5, 8.0, 10.1 (2014 ed), Note Pro 12.2 Galaxy TabPro 8.4 LTE, 10.1 Galaxy Tab4 8.0, 10.1 (Tab4 7.0" needs verification) Galaxy Tab3 - 8.0, 10.1 (Tab3 7.0" needs verification)	Not: Galaxy S3/S4/S5 Mini's Not: Galaxy Ace / Ace 3 (GT-S7270) Not: Galaxy Core / Core Prime / Rugby Pro / Win Not: Galaxy Grand 2 / Grand Neo Not: Galaxy Mega 5.8 / Premier / Centura S738C Not: Galaxy Tab 7.7 plus / Tab 2
<b>Sony</b>	SGPT111JP/S, SGPT112TW/S, SGPT211JP/S, Xperia AX (SO-01E), Xperia ACRO S (LT26W), Xperia T (LT30P), Xperia TX LT29i, Xperia Z2a, Xperia Z (C6602), Xperia Z ULTRA (C6802), Xperia Z1, Xperia ZL (C6502), Xperia ZR (C5502), Xperia Z3 (D6653) Xperia C, J, M, Xperia U, UL, V, VC, VL, Tablet Xperia Tablet S, Z	Not: Xperia T Xperia Z
<b>Toshiba</b>	AT700/35D	
<b>Wexler</b>	Ultima 7, Ultima 7 Twist, TAB 8q, TAB 10q, Ultima Octa, Mobi 7	
<b>Xiaomi</b>	MI-2s, Red Rice, Red Rice Note	
<b>ZOPO</b>	ZP980	
<b>ZTE</b>	U950, U985, V967S, ***Ensure USB Host Support w/ OTG Troubleshooter app for ZTE	Not: Z932L, Quartz